



**SKIDS DE
CONDICIONAMENTO
DE AMOSTRA**



WWW.USE.COM.BR

m-value meter

con 2000 m-value

Analyser for acid/base titration

Used in power plants, in particular, for determining the acid capacity or m-value in cooling-water circuits.



Features and peculiarities

- End-point determination by pH measurement
- *Very precise end-point determination of equivalence point via evaluation of inflection point of titration curve*
- Extremely precise metering of titrant through the use of flow inducers with stepping motors
- Acrylic flow-through holder for mounting the pH measuring chain and the sample
- Ingenious method for determining the sample volume by means of siphons incorporated in the flow-through holder